### Components

Bending

### **Profile**

+Profile Cutting

Lorem ipsum

- +Profile Jointing
- +Profile Installation

### **Optional Accessory**

- +Glare Shield
- +Adjustable Mounting Bracket

## **Light Installation**

### **Cable Jointing**

### **Light Uninstallation**









# Components

# Glare Shield (Optional) Wall Washer Light Male & Female Connector (Optional) Mounting Profile Adjustable Mounting Bracket (Optional)

### OPTIONAL PROFILE



Serrated Aluminum Profile H50



Serrated Aluminum Profile H36




Bendable Serrated Aluminum Profile H36 (HB)



Bendable Serrated Aluminum Profile H36 (VB)

# Bending



FXN 3525



Bendable Serrated Aluminum Profile H36 (HB)




Bendable Serrated Aluminum Profile H36 (VB)



# Profile

### **PROFILE CUTTING**

The profile can be cut according to your need.



If the section end is more than 100mm away from the hole, drill a 5mm hole 20mm away from the end to fasten the profile.

### Recommended Cutting Tool








Remove the burr after cutting to prevent scratches to the light that could cause water ingress and damage.

### **PROFILE JOINTING**






The misalignments shown above will cause the light to bend improperly and may lead to wrinkles or fractures in the PCB

### **PROFILE INSTALLATION**











# Profile



# **Optional Accessory**

### **GLARE SHIELD**








# Optional Accessory

### ADJUSTABLE MOUNTING BRACKET

Step 1




Use screws to fasten the brackets on the profile. 2~3 brackets are recommended for every 1m of profile.






Rotate the profile to one side and mark out the holes.






Fasten the brackets with self-tapping screws.



Step 4






Step 5




Turn on the light and adjust the profile to your preferred lighting angle.




The adjustable mounting bracket can be equipped with bendable profile but the rotation angle will be limited.









# ight Installation



Make sure the angle between the light and profile is not bigger than 30°, otherwise inside PCB might be damaged.

When installing the light inside a H36 profile, leave about 20mm of the light out of the profile.






Make sure the light end is not pulled or placed under extra force. Long-term tension at the cable entry could cause water ingress.

When installing the light inside a H50 profile, the light end can be aligned with the profile end.



Profile H50





Make sure the light end is not pulled or placed under extra force. Long-term tension at the cable entry could cause water ingress.






Make sure there are no scratches on the cable sheath, otherwise water ingress may occur.






# Cable Jointing



Align the red dots, insert the connectors then turn clockwise to tighten the connectors.
Turn on the light and test it.




Please use the professional waterproof box or waterproof connector to do the cable treatment.



Wrapping the cable with adhesive tape only is not reliable, it will cause water ingress.

# Light Uninstallation



Insert a screwdriver at the bottom of light and lift the light slowly. Be careful about the angle between the light and profile, it should not be bigger than 30°.